Coolcopy 1 Operation Guide

Operation for quick duplication:

1. Power on and wait for 4 ~ 5 seconds to warm up.
2. Open all drives.
3. Insert the master into the CD-ROM (1st drive).
4. Insert the blank CD(s) into the CD-R (2nd drive).
5. Close all drives.
6. It will automatically start to copy as soon as you close all the drives.
7. When finish, it will eject the CD(s) by itself.
8. If continuing to copy the same CD(s) just insert more blank CD(s) (Follow steps 6 &7).
9. If changing master CD(s).
    a. All trays need to be open.
    b. Insert master into CD-Rom (1st drive) then close it.
    c. Insert blank CD into CD-RW (2nd drive) then close it.
    d. (Follow steps 6 & 7).
10. Remove all CD(s) when finished copying and turn off.